

ROCKER RUNNER MEASUREMENT INSTRUCTIONS

How to measure holes for replacement rocker runners:

These measurements are necessary to order correctly bored runners that will fit your chair.

- Turn the rocker upside down
- Measure the distance from the center of the front post to the center of the back post. In most cases the distance will be 18 ¾” but occasionally it will vary.
- This dimension will enable us to know what distance to bore the holes for the new runner.
- Measure the diameter of the hole in the runner – it should be ¾” or 7/8”
- Price for a pair of runners including shipping is \$ 35.00
- Rocker runners are available in a variety of colors and unfinished.

Please call 615-384-8477 to receive assistance or to place an order.

Runners are available for the following models

BRADLEY	# 200 & 1200
BROOKFIELD	# 1900 & 11900
COLLEGIATE	# 250SC & 250SM
CUMBERLAND	# 250 & 1250
PLANTATION	# 850 & 1850
CARRINGTON	# 240
FARM HOUSE	# 400
ALEXANDER	# 213
YOUTH	# 201 & 851
RED GRANDIS	# 700 & 850