

#1900 ROCKER ASSEMBLY INSTRUCTIONS




Thank you for purchasing a quality select hardwood rocking chair. If you should have any comments or questions please call the toll-free number below between 8:00 AM and 5:00 PM CST Monday through Friday. Again, we appreciate your business and hope you get many years of enjoyment from this chair.

NOTICE: The Rocking Chair product that you have purchased requires some assembly. As with all furniture, proper assembly is necessary for the safe and comfortable use of your rocker. Hinkle Chair cannot be responsible for any damage or injury that results from improper assembly of the chair. Please read and follow these instructions carefully and in sequence. If you have any questions please call The Hinkle Chair Company helpline (800) 251-3025 or contact us on our website at www.hinklechair.com.

PLEASE NOTE: The Rocker you have purchased is depicted above. Many of our rockers assemble with the exact same steps and the only difference is the appearance of the chair. If the rocker depicted in the assembly steps does not look the chair you purchased, it assembles with the same steps. Also, all references of left and right in these instructions are from the perspective of standing in front of the chair facing it, not sitting in it.

ROCKING CHAIR ASSEMBLY INSTRUCTIONS



PARTS INCLUDED:

- 1 – Chair Back (A)
- 1 – Chair Seat (B)
- 2 – Back Spindle (C-1)
- 3– Front Spindles (C-2)
- 2 – Rocker Sides (D-L/D-R)
- 2 – Runners (E-L/E-R)

- 10 – Wooden Buttons
- 10– Hex Head Screws
- 1 – Hex Wrench
- 4 – Seat Screws
- 4 – Runner Nails

TOOLS REQUIRED FOR ASSEMBLY: (NOT INCLUDED)

- Standard Hammer (using folded towel/heavy cloth to protect the finish)
- Phillips Screwdriver

**** Attention/Stop****



Hinkle Chair Company has made every effort to provide you with a ready-to-assemble product that has the same quality as our fully assembled rocking chairs. In the unlikely event that there are incorrect, missing parts, or the parts become damaged during shipping, following the instructions below will protect you(The Customer) from accepting responsibility for a product that is damaged or incomplete.

- 1st) Inspect all parts for any imperfection that might have occurred during shipping.
- 2nd) If there are missing or damaged parts the chair must be returned in the original packaging before any credit can be issued. In the case of damaged parts, individual parts will be sent as replacements.
- 3rd) Lay all the parts out as shown on page 2. This will help you identify and familiarize yourself with the individual parts and will make assembly much easier.
- 4th) When you have determined that all parts are present and you are familiar with all of the assembly steps begin to assemble the rocker

This product is intended for a covered porch or indoors. This product should be cleaned weekly as you would with any other wooden furniture product.

If at any time during assembly you need assistance please contact the Hinkle Chair Company helpline at (800) 251-3025 M-F 8 AM to 5PM CST.

STEP 1:

Place left side of rocker D-L on cardboard shipping box with mortised holes facing up. Insert the back A into the pre-drilled mortises in the back post. Tap in with hammer until fully inserted Fig. 1



Fig. 1

Insert the back spindles C-2 into the pre-drilled hole in the back post below the back just inserted. Note: these spindles are interchangeable. Fig. 2



Fig. 2

STEP 1:

Place Front Spindles C-1 (square) into Side D-L front post until fully inserted. Note: the large cross piece is the headrest and should be at the top of the chair. Twist spindles until oriented correctly. Note: C-2 square spindles go in the bottom two pre-drilled holes. Fig 3



Fig. 3

Place Front Spindle C-1 (round) into pre-drilled hole in front post and tap in with hammer until fully inserted. This spindle goes in the top pre-drilled hole. Fig. 4



Fig. 4

STEP 1:

Place Seat B just below the arm on chair side D-L. Note: Do Not place seat under any round dowels in the side of the chair. You will attach the seat in a later step. Fig. 5



Fig. 5

Place chair side D-R over tenons facing up and align with pre-Drilled holes and mortises in chair side D-R. Tap down until fully inserted. Fig. 6



Fig. 6

STEP 2:

Note: Correct placement of seat before installing any hardware. Check both sides to ensure it is correct. Fig. 7



Fig 7

STEP 2:

Place Hex Head Screw in the top pre-drilled hole on back post and thread in. Do not fully tighten at this point, make sure you make contact with chair back A tenon so the chair will hold together for the following steps.

Fig. 8




Fig. 8

STEP 2:

Move down the post to the next pre-drilled hole and insert another Hex Head Screw through the back post and into the chair back A. Again, do not fully tighten at this point.

Fig. 9



Fig. 9

STEP 2:

Place the Hex Head Screw into the pre-drilled hole in the front post and tighten with wrench provided. Thread in and do not fully tighten as before. Continue with the other pre-drilled hole in the front post.

Fig. 10



Fig. 10

STEP 3:

Flip chair onto the other side careful to hold the unfastened side in place. Repeat the previous step on this side as in Step 2.

Fig. 11



Fig. 11

STEP 4:

Using the seat screws provided, insert screw in pre-drilled hole on upper side dowel. There is a pre-drilled hole in the under seat piece. Align screw to enter the pre-drilled hole. Once the screw begins to thread move to the next screw in the rear of the chair. Get that screw started as before and move to the other side. Once all are started, fully tighten each screw. Fig. 12



Fig. 12

STEP 4:

Align the runner over the post tenons. At this point ensure that the pre-drilled hole in the runner is facing to the inside. Tap the runner on the tenons with a hammer until fully seated. Repeat for the other side. Fig. 13



Fig. 13

STEP 4:

Insert the nail on the inside of the runner and tap in with a hammer until flush with the surface. Repeat for the rear of the rocker on this side. Rotate rocker on the other side and repeat this process.

Fig. 14



Fig. 14

STEP 5:

Begin on one side and place the provided buttons into the pre-drilled holes and tap button in flush to the surface. Repeat for all 10 holes and your rocker is now completely Assembled. Fig. 15



Fig. 15

CARE TIPS

LISTED BELOW ARE SOME TIPS TO HELP KEEP YOUR FURNITURE LOOKING NEW.

To preserve the finish on stained or pure white furniture it is highly recommended that they either be placed indoors or in a protected environment such as a covered porch. In any case the finish will last longer and look better if kept out of direct sunlight and blowing rain. This furniture is not intended to be used in an unprotected environment. The sun and rain will weather the varnish finish if left out in the elements over time (6 months to one year depending on the climate). Our furniture products need the same attention as any other solid wood furniture and monthly cleaning with any quality household furniture polish will keep your furniture looking new for many years to come. If your climate has high humidity, even if you follow the recommended cleaning intervals above, you may have problems with mold or mildew. Use a commercially sold furniture cleaner and follow the directions on the product to remove mold and mildew.