

#240 SLAT ROCKER ASSEMBLY INSTRUCTIONS




Thank you for purchasing a quality select hardwood rocking chair. Your chair comes with a rich heritage and will become a treasured family heirloom. If you should have any comments or questions please call the toll-free number below between 8:00 AM and 5:00 PM CST Monday through Friday. Again, we appreciate your business and hope you get many years of enjoyment from this chair.

NOTICE: The Rocking Chair product that you have purchased requires some assembly. As with all furniture, proper assembly is necessary for the safe and comfortable use of your rocker. Hinkle Chair Company cannot be responsible for any damage or injury that results from improper assembly of the chair. Please read and follow these instructions carefully and in sequence. If you have any questions please call (800) 251-3025 and one of our helpful representative will be happy to help you.

PLEASE NOTE: The Rocker you have purchased is depicted above. Many of our rockers assemble with the exact same steps and the only difference is the appearance of the chair. If the rocker depicted in the assembly steps does not look the chair you purchased, it assembles with the same steps. Also, all references of left and right in these instructions are from the perspective of standing in front of the chair facing it, not sitting in it

ROCKING CHAIR ASSEMBLY INSTRUCTIONS



PARTS INCLUDED:

- | | |
|--|--------------------------------|
| 1 – Chair Back (A) | 8 – Wooden Buttons (F) |
| 1 – Chair Seat (B) | 8 – Hex Head Bolt w/wrench (F) |
| 1 – Back Spindles (C-1) Round | 4 – Runner Nails (F) |
| 2 – Front Spindles (C-2) Square | 2 – Dowel Screws (F) |
| 2 – Rocker Sides (D-L/D-R) (facing chair from front) | |
| 2- Runners (E) | |

TOOLS REQUIRED FOR ASSEMBLY: (NOT INCLUDED)

- Dead Blow Hammer or
- Standard Hammer (using folded towel/heavy cloth to protect the finish)

**** Attention/Stop****



Hinkle Chair Company has made every effort to provide you with a ready-to-assemble product that has the same quality as our fully assembled rocking chairs. In the unlikely event that there are incorrect, missing parts, or the parts become damaged during shipping, following the instructions below will protect you(The Customer) from accepting responsibility for a product that is damaged or incomplete.

- 1st) Inspect all parts for any imperfection that might have occurred during shipping.
- 2nd) If there are missing or damaged parts the chair must be returned in the original packaging before any credit can be issued. In the case of damaged parts, individual parts will be sent as replacements.
- 3rd) Lay all the parts out as shown on page 2. This will help you identify and familiarize yourself with the individual parts and will make assembly much easier.
- 4th) When you have determined that all parts are present and you are familiar with all of the assembly steps begin to assemble the rocker

This product is intended for a covered porch or indoors. This product should be cleaned weekly as you would with any other wooden furniture product.

If at any time during assembly you need assistance please contact the Hinkle Chair Company helpline at (800) 251-3025 M-F 8 AM to 5PM CST.

STEP 1:

Place right side of rocker D-R on cardboard shipping box with mortised holes facing up. Place Back (A) over the pre-drilled holes to verify the orientation of the back. This is just to ensure proper placement Fig. 1



Fig. 1

Once orientation is established, flip over to expose the pre-drilled holes and insert a Hex Head Bolt (F). Thread into the insert in the Chair Back (A). Using the wrench provided run bolt in halfway. Repeat for the lower Hex Bolt. Fig. 2



Fig. 2

STEP 2:

Place the Back Spindles (C-1) into mortised hole. Tap in with a hammer until it hits the bottom. Repeat for the other Spindle Fig. 3



Fig. 3

Place Front Spindle (C-2) in mortised hole. Tap in with a hammer until it hits the bottom. Repeat for other Spindle. Fig. 4



Fig. 4

STEP 3:

Place left side of rocker (D-L) over the partially assemble chair. Line up the spindles with the corresponding mortises. Tap with a hammer until the left side is all of the way on the tenons. Fig. 5

Insert Hex Bolt (F) into pre-drilled in Rocker side (D-L) and thread in half way as on other side. Repeat for the lower hole. Fig. 6



Fig. 5



Fig. 6

STEP 4:

Place Seat (B) between Rocker Side L/R and align the pre-drilled holes in Rocker Side (D-L). Insert Hex Bolt (F) into pre-drilled hole and thread in half way. Repeat for other hole. Fig. 7

Flip chair onto the other side and repeat the previous step on the other side. Fig. 8



Fig. 7



Fig. 8

At this point of assembly, go back to all Hex Bolts and fully tighten. I may help to alternate sides as tighten these.

STEP 5:

Place the Hex Screw in the pre-drilled hole on the lower part of the front post. Note: This does not have a threaded insert and can be stripped out if tightened too tight. Fig. 9

Repeat for the other side. Fig. 10



Fig. 9



Fig. 10

STEP 6:

Note: when choosing the Runner, the pre-drilled holes go to the inside of the rocker.

Place the mortised hole on Runner (E) over the tenon on the front post of the Rocker Side (D-R). Rotate the Runner (E) over the tenon on the back post. With a hammer gently tap on the Runner(E) alternating from front to back. Tap nails provided into the predrilled hole until flush with the surface. Repeat for all four. Fig. 11

Once all fasteners are fully tightened, place the Button over the fastener into the pre-drilled hole. Tap in with a hammer and repeat for all 8 holes. Assembly is complete.



Fig. 11



Fig. 12

CARE TIPS

LISTED BELOW ARE SOME TIPS TO HELP KEEP YOUR FURNITURE LOOKING NEW.

To preserve the finish on stained or pure white furniture it is highly recommended that they either be placed indoors or in a protected environment such as a covered porch. In any case the finish will last longer and look better if kept out of direct sunlight and blowing rain. The finish on this furniture will last for a lifetime if used indoors. This furniture is not intended to be used in an unprotected environment. The sun and rain will weather the varnish finish if left out in the elements over time (6 months to one year depending on the climate). Our furniture products need the same attention as any other solid wood furniture and monthly cleaning with any quality household furniture polish will keep your furniture looking new for many years to come. If your climate has high humidity, even if you follow the recommended cleaning intervals above, you may have problems with mold or mildew. To remove the mold and mildew dilute one ounce of bleach into sixteen ounces of water and apply with a soft cloth. More than one application may be necessary. Allow to dry and apply furniture polish to protect the finish.