

REPLACEMENT ROCKER SEAT INSTRUCTIONS

SLAT OR RUSH

Pricing (includes shipping).

\$45.00 for the Child slat

\$50.00 for the Adult/Jumbo slat

\$60.00 for the Adult Rush

Available Colors

Black, Maple, White, and Unfinished.

If within the warranty period, we can do specialty colors.

Rush seats are only available in White and Maple.

To remove and replace a slat or rush seat for a rocking chair

First, remove one of the arms - this is done to make seat removal possible.

Insert a screw into the center of the button cover and turn the screw – the button cover should pop off.

Use a Phillips Head screwdriver to remove the screws from the front and back of the arm

Then remove the 4 screws from the underside of the rounds below the seat.

Lift the seat toward the side of the removed arm and then remove the seat.

Attach the seat, reattach the arm, and insert new screws and new buttons.

Seats are available for the following models:

Standard Adult Slat

100S- Cracker Barrel

200S- Bradley

217S- Cooper Creek

250S- Cumberland

400S- Farm House

850S- Plantation

1900S- Brookfield

Youth Rocker

201S- Bradley

821S- Cracker Barrel

Jumbo Adult Slat

1100S- Cracker Barrel

1200S- Bradley

1250S- Cumberland

1850S- Plantation

Standard Adult Rush

100R- Cracker Barrel

200R- Bradley

250R- Cumberland

Special Seat

214S- Alexander